



USER MODEL UISA




0 63




0 31

Condition Register




0 31

Floating-Point Status and Control Register



03 1


User-Level SPRs



0 31


USER MODEL VEA

Time Base Facility (for Reading)



SUPERVISOR MODEL OEA

Machine State Register



03 1

Supervisor-Level SPRs

See table for list of supervisor-level SPRs.

Development Support SPRs

See table for list of development-support SPRs.